




THE AUTOMOTIVE LIGHTING BENCHMARK



INSTALLATION GUIDE

MOTORCYCLE SEPARATE HIGH/LOW HID SYSTEM




WARNING: By reading this document, I agree it is only to be used as an educational guide. Morimoto Lighting makes no guarantee on any finished results, nor are they to be held responsible for any damage, misuse, or personal injuries. Use at your own risk. If you are unable to clearly understand and adapt the information below to your own application, professional installation is recommended.

TABLE OF CONTENTS

SYSTEM DIAGRAM

P.3



2X BALLAST COMPUTERS

HARNESS INSTALLATION


P.4



2X AMP IGNITERS

BULB INSTALLATION

P.4



2X CYCLE-SPEC RELAY HARNESSES

BALLAST INSTALLATION

P.5




2X HID BULBS



2X BULB WIRES

OPTIONAL PARTS



1X CARBON FIBER BALLAST BRACKET

SPECIAL NOTE



Morimoto MotoCycle wire harnesses are designed and built specifically for use on a motorcycle / scooter. Wire lengths of the harness are configured so that the harness control module can fit under the seat next to the bike's battery. The output and input of the harness are elongated to receive and send signal from the OEM headlight connector at the front of the bike without splicing or modification.

This system is designed to retain the stock single low beam and separate single high beam. If you wish to have both on at the same time for either low or high beam, a retrofit is recommended and necessary.




SYSTEM DIAGRAMS




NOTE: System diagrams are to be used for reference purposes only. If you are unsure of the installation procedure for any individual part, review its install procedure prior to proceeding.

Low Beam Configuration




High Beam Configuration




HARNESS INSTALLATION



WATERPROOF



When installing the harness, ensure every connection is securely fastened and can't loosen over time.



The harness' ground and battery 12V+ ring terminals must be secured to their appropriate positions on bare metal. Remove any paint, rust/corrosion, or plastics before first!


BULB INSTALLATION




CAUTION: HOT!




HANDLE ONLY WITH BLACK PLASTIC BASE



Using an alcohol wipe, clean the bulb glass of any dust, dirt, and finger prints.



Install bulb into housing, replacing the stock halogen bulb.



BALLAST INSTALLATION







DO NOT IGNITE UNTIL FULLY CONNECTED!



WATERPROOF

SCHEMATIC



-END-